



## How to change switch's ip address


1. Access to switch



2. System > System Settings



3. Change ip address, subnet mask and gateway, press apply



4. Save configuration

